




Raleigh™ Two Handle Gooseneck Kitchen Faucet, Less Spray, With Deckplate, Chrome, 1.8GPM

Replacement Parts / Repuestos



Part Pieza	Description Descripción	Part # Pieza #	USN # USN #
1	Handle H / Llave H	186881	
2	Handle C / Llave C	186871	
3	Screw / Tornillo	186858	
4	Inverter / Inversor	186855	
5	Bonnet Nut / Tuerca del Bonete	158765	
6	Washer / Arandela	186847	
7	Cartridge H / Cartucho H	186936	322096815
8	Cartridge C / Cartucho C	186926	322096440
9	Gasket / Junta	186841	
10	Aerator / Aireador	186929	322096659
11	Wearable ring / Aro desmontable	186852	322096652
12	Clip / Sujetador	186854	322096453
13	O-Ring / Aro Tórico	186843	322096450
14	Quick Install Nut / Tuerca de Instalación Rápida	186846	322096434

Part #: 158074
USN #: 320280242